




7466.0025

Onderdelen informatie
Erzatzteil information
Spare part information
Information de pièces







POS:	Art.No.:	Omschrijving:	Aantal:
1	CS9089.0376	Oven fan with polygonal blades 180x77	
2	CS9089.0075	Thermostat 1ph. safety.350°C 5519562030	
3	CS9102.0180	Heating element 6000 W 230V	
4		Bearing pin for grids rack	
5	CS9089.0655	Grids rack	
6	CS9089.0200	Seal black	
7	CS9089.0305	Spindle for door	
8	CS9089.0306	Bush for door pin	
9		Door with glass	
10		Fan guard grid	
11		Condensation collector tray	
12	CS9102.0213	Adjustable foot	
13	CS9089.0160	Door microswitch	
14		Whiting for closing	
15	CS9393.0330	Oven light	
16	CS9089.0170	Kit lamp socket gasket	
17	CS9089.0288	Main thermostat	
18	CS9089.0255	Motor 1ph hp0,25	
19	CS9102.0470	Oven door knob	
20		Oven glass	
21		Silk-screened knob for oven	
22	CS9999.0062	Fluorescent pilot light (green)	
23	CS9999.0061	Neon pilot light (orange)	
24	CS9089.0125	Timer 120'	
25		Motor capacitor 12,5uF	
26		Terminal block	
27	CS9089.0585	Contacteur 20A	
28	CS9089.0380	Motor rotation inverter	
29	CS9089.0565	Electronic buzzer board	
30	CS9089.0240	2-way solenoid valve with filter	
31	CS9089.0210	Nozzle for pipe humidifying	
32	CS9102.0125	Motor shaft seal	
33		2 speed switch	
34	CS9162.5310	Energy regulator 16A 220V	