

USER'S INSTRUCTIONS

Pre-rinse unit with Add on Tap Bench-mount mixing faucet



INSTALLATION INSTRUCTIONS

INSTALLATION

- 1) remove the washers and the lock nuts (a) from the threaded fixing shaft
- 2) insert the threaded shaft in the installation surface hole
- 3) fix the faucet to the installation surface using the washers and the lock nuts (a)

	BENCH-MOUNT MIXING FAUCET - USER'S INSTRUCTIONS -	04/05/2018 Rev. 1.0
--	--	----------------------------

- 4) remove the screw of the faucet (b)
- 5) Install the **Wall Bracket (2)** onto the **Stainless Steel Pipe (1)**. If you want to install the Wall Bracket underneath the Add-On Tap, remove the O-Rings and the chrome-plated plaque from the lower end of the Stainless Steel Pipe, install the Wall Bracket and place the O-Rings back into their seat.
- 6) Insert the **Stainless Steel Pipe (1)** in the Faucet's seat (see **Detail B**). Make sure the hole in the lower end of the Pipe is aligned with the hole in the Faucet's seat. Lock the Pipe to the Faucet using the screw (b) provided with the Faucet.
- 7) If the **Wall Bracket (2)** is too long, remove the screw on the round flange (see **Detail A**) using the Allen key provided with the Pre-Rinse Unit. Saw off the Wall Bracket Rod to the desired length (please note the rod has a metallic core). Re-assemble the round flange to the shortened Bracket and tighten the screw. Screw the Wall Bracket to the wall.
- 8) Install the **Spray Gun Bracket (3)** onto the Stainless Steel Pipe (1). Do not tighten its screws yet.
- 9) Install the **Spring Holder (4)** onto the Stainless Steel Pipe (1) at about 15-20 cm (6-8") from the upper end of the Pipe. Tighten the screw on the Spring Holder firmly using the Allen key provided with the Pre-Rinse Unit. Make sure the Spring Holder will not slide along the S/S Pipe.
- 10) Connect the **Flexible Hose (5)** to the upper end of the Stainless Steel Pipe (1) using the **Gasket (6)** provided with the Pre-Rinse Unit.
- 11) Insert the Flexible Hose (5) through the **Riser Spring (7)**. Place the Spring on the Spring Holder (4) and make sure it is firmly in place.
- 12) Assemble the **Spray Gun (8)** to the other end of the Flexible Hose (5), using the **Gasket (9)** provided with the Spray Gun. Tighten the Spray Gun to the Flexible Hose by hand, do not use a wrench.
- 13) Install the **Swivel Nozzle (10)** onto the Add-On Tap and tighten its screw.
- 14) Adjust the position of the **Spray Gun Bracket (3)**. Tighten the screws on the Spray Gun Bracket firmly, using the Allen key provided with the Pre-Rinse Unit. Make sure that the Spray Gun Bracket will not slide along the Stainless Steel Pipe (1) and will not move laterally.
- 15) connect the inlet pipes/flexible hoses to the water net
- 16) Test the assembled Pre-Rinse System before using.

Operating parameters:

Water output: Spray Gun 16 l/min / Spout 24 l/min

Maximum water temperature and pressure: < 85° and < 1 Mpa

Raccomended water temperature and pressure: < 65° and < 0,5 Mpa

USE:

- Do not move swivel nozzle violently and do not hang anything on the nozzle
- Keep the faucet's surfaces clean and dry using a soft cloth, in order to prevent limestone or corrosive substances fouling (do not use aggressive and/or corrosive detergents)
- Remove the aerator often and keep it clean with suitable solvents and water
- Faucet is suitable for use with water only, do not mix water with other substances

CLEANING INSTRUCTIONS

**BENCH-MOUNT MIXING FAUCET
- USER'S INSTRUCTIONS -**

04/05/2018

Rev. 1.0

- DO NOT clean the faucet surfaces when hot. They should be cleaned when they are at room temperature
- DO NOT use aggressive and / or corrosive detergents
- DO NOT use abrasive cleaning pads
- After cleaning with soft detergent rinse well the surfaces with cold water to remove any traces of chemicals and dry them with a soft cloth.
- Avoid contact between detergents and rubber gaskets

